

User manual

MD Link

Our MD Link helps you control your solar park, inverter, battery, etc. as a virtual production plant optimized for the market. The best place to install the MD Link is near the internet router, connected to the power grid and to the same local area network (LAN) where the inverter is connected. The settings take place automatically.

What does the kit include?

- **A** MD Link (Dusun)
- **B** Network cable (yellow)
- **C** Power adapter and power cord (white)



How to connect the MD Link?

1. Connect one end of the network cable to the LAN port of the internet router and the other to the MD Link.
2. Connect the power cord to the power adapter, plug the adapter into the power grid and connect the other end of the power cord to the MD Link.
3. Log into **app.markedroid.com** to get access to your virtual power plant info.

Meaning of MD Link lights

Light	Meaning	Solution
● Breathing (1 min)	The MD Link is in working order	MarkeDroid (MD) service is working as expected
● Breathing	Connected to MD, not inverter	Check the operation and settings of the inverter
● Breathing	Connected to inverter, not MD	Check your internet connection
● Blinking	No MD or inverter connection	Check if the MD Link is in the same network as internet & inverter
● Blinking	No network connection	Check the network cable connection
● Constant	The MD Link starts working	If it doesn't change, please contact us